

Contact: Randy Wardell - President

Phone: 954-607-2189

Email: thebuzz@joyoffusing.com

Website: www.joyoffusing.com

C105 Foot Casting Mold & F500 Stackable Fusing Foot Rings **Fuse a stemmed foot to a draped bowl using this mold & ring system**

Advance to the next level by adding a 'blown glass style' stemmed foot to a draped bowl. The bowl shown below was shaped and the foot was added on an M35 Starfire mold (also available from Wardell Products).

The 'Starfire Bowl with Stem Foot' process:

- Create a 10" to 12" (25 to 31 cm) dia flat-disk design then fuse it to your desired fusing level.
- Cast a 3-1/4" (85 mm) x 1/4" (6 mm) glass disk in the C105 Foot Casting Mold using 90 grams of leftover scrap glass pieces from your project.
- Stack the F500 Foot Rings to create a 'V' shaped cone assembly. These precision cut, reinforced rings will retain their thickness and shape throughout the drape firing process.
- Place your pre-fused flat-disk on the M35 Starfire mold, then center the Foot Ring cone assembly and stack the Cast Foot disk on top of the cone.
- Set the kiln controller to the recommended drape fire schedule (in the 12 page Instruction Booklet) to shape the bowl, create the stemmed foot profile and fuse the foot - all in the same firing.

Package contains:

- **C105 Foot Casting Mold**
- **1 set- F500 Stackable Fusing Foot Rings**
- **4 page Instructional Booklet**

F500 Stackable Foot Ring 2-Pack refills are available separately packaged in an attractive hanger-display ultra-clear plastic container.



Suggested retail price - \$58.95 US - Available Now

Wardell Products P.O. Box 480069, Fort Lauderdale, FL 33348-0069

Email: thebuzz@joyoffusing.com • Ph: 954-607-2189 • Fax: 754-551-5462 • Website: www.joyoffusing.com